



REVISION HISTORY LOCK CORE INSTALLATION INSTRUCTIONS FOR LOCKING ASSEMBLY DATE DESCRIPTION SOLD WITHOUT LOCK CORES: (PART NO. E5-9-335-YY1 & E5-9-365-YY1) K 12APR2021 ASM/CAD PRN: P2021-0690 LOCK CORE INSTALLATION: 1. SQUEEZE SPRING LEG TOWARD CENTER OF PLUG. D 3. VERIFY ORIENTATION OF LOCK EXTENDER AS SHOWN. 4. WITH WAFERS PROTRUDING 90° CLOCLWISE FROM LOCK SYMBOL, 2. WITH SPRING LEG DEPRESSED, ROTATE PLUG 90° COUNTER INSERT LOCK CORE INTO DRIVER. CLOCKWISE AND PULL PLUG OUT OF DRIVER. 5. INSERT KEY INTO LOCK CORE AND TURN 90° CLOCKWISE TO VERIFY LOCK CORE IS FULLY SEATED AND OPERATING PROPERLY AFTER INSTALLATION. THIRD ANGLE PROJECTION MILLIMETERS [IN] E5 QUAD LATCH (WING KNOB) OLERANCES UNLESS OTHERWISE NOTE SURFACE AREA ALL DIMENSIONS WITHOUT TOLERANCES ARE FOR REFERENCE ONLY. M22 X 24.9 HOUSING PROPRIETARY ITEM J-E5-9-3 NX EXCEPT FOR USES EXPRESSLY GRANT IN WRITING, INFORMATION DISCLOS HEREON IS CONFIDENTIAL AND ALL RIGHTS, PATENT AND OTHERWISE, ARE RESERVED BY SOUTHCO, INC. SHEET 3 OF 3 PER ASME Y14.5M-1994 13JUL2004 1:1 5 3 2